

Datos Técnicos

Luminaria para uso interior
Factor de Potencia: 1
Lámpara utilizada:

LED SMD 127,2W 300mA 2700K
16680lm

Dimmable DALI / DSI

Se recomienda que la instalación sea realizada por un profesional.

Aviso: Si el cable flexible o cordón de esta luminaria está dañado, deberá sustituirse exclusivamente por el fabricante o su servicio técnico o una persona de cualificación equivalente con objeto de evitar cualquier riesgo.

Instrucciones para la limpieza

Utilizar un paño suave, humedecido con agua y detergente neutro si fuera necesario. No utilizar alcohol o otros disolventes.

Technical Data

Light fitting for indoor use only
Power Factor: 1
Bulb used:

LED SMD 127,2W 300mA 2700K
16680lm

Dimmable DALI / DSI

A professional electrician should be responsible of the light installation.

Warning: If the wire or flexible cord is damaged, it has to be changed exclusively by the manufacturer, his technical service or a qualified personnel in order to avoid any risk.

Cleaning Instructions

Use a soft damp cloth, with soap or neutral detergent. Do not use alcohol or other solvents.



Sólo aislamiento básico. Las partes accesibles están conectadas a una toma de tierra. Toma de tierra obligatoria.

Basic insulation only! Accessible parts connected to earth lead. Apparatus must be fully earthed!




Este símbolo en su equipo o embalaje indica que el presente producto no puede ser tratado como residuo doméstico normal, sino que debe entregarse en el correspondiente punto de recogida de equipos eléctricos y electrónicos. Para recibir información detallada sobre el reciclaje de este producto, por favor, contacte con su ayuntamiento, su punto de recogida más cercano o el distribuidor donde adquirió el producto.

This symbol on the product or its packaging indicates that it must not be treated as household waste. It should, in fact, be handed in at a recognised collection point for recycling electrical and electronic equipment. For more detailed information about the recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

230 V - 50 Hz

SOHO C 112 LED

Instrucciones de Montaje / Assembly Instructions




marset




marset


1.




2.




3.




4.



5.



6.

**Atención!**

Desconectar la conexión a red antes de ser manipulada.

Warning!

Disconnect power supply before installation.

1. Fijar el soporte (A) mediante los tornillos y tacos que se suministran (B), pasando los cables de red por el orificio.
2. Realizar las conexiones eléctricas: Conectar los cables N, L y \oplus en la caja de empalmes de 3 polos (C) y los cables de regulación DALI D1 (cable gris) y D2 (cable negro) en la regleta de 2 polos (D).
3. Fijar la pantalla (E) mediante las tuercas y arandelas suministradas (F) tal y como muestra la figura.
4. Conectar el conjunto eléctrico (G).
5. Fijar el conjunto eléctrico utilizando las tuercas (H) suministradas.
6. Fijar el difusor (I) roscando la pieza (J).

1. Fix ceiling plate (A) in position using the plugs and screws provided (B), passing the power cable through the hole.
2. Connect the wiring: Connect N, L and \oplus wires in the 3 poles' terminal strip (C) and the DALI control wires D1 (grey wire) and D2 (black wire) in the 2 poles' terminal strip (D).
3. Attach shade (E) using the nuts and washers provided (F) as shown in Fig. 3.
4. Connect unit (G).
5. Fix unit (G) using the nuts (H) provided.
6. Attach the diffuser (I) screwing up piece (J).